# SCSI View Reader

Our easy-to-use software provides the detailed protocol, timing and performance information you'll need to zero in on even the most elusive SCSI problems.

SCSI-View Reader allows remote analysis of hardware file captures. Also, it can be downloaded as a demonstration program for use with the sample capture files.

## Software

To install the reader program on your download system, create a temporary directory; for example, **c:\temp**, and download **svreader.exe** to this directory.

- Select **Start, Run**.
- Enter **c:\temp\svreader** to uncompress the setup files.
- Select **Start, Run**.
- Enter **c:\temp\setup** to install it.

To install SCSI-View Reader on another computer, prepare a blank diskette and place it in the diskette drive.

- Select **Start, Run**.
- Enter **c:\temp\svreader a:** where **c:\temp** is the directory of the downloaded file, and where **a:** is your diskette drive.

Use the software's on-line help for instructions.

**SCSI-View Reader & Demonstration Software Notes:**

- Open our sample files for demonstration purposes by selecting the **Analysis** menu. SCSI activity can be viewed as **Timing, Phase (State)**, **Command** and **Performance Analysis** views.
- Use the right mouse button, or press **F2**, to bring up the **Search** pop-up window in the **Phase** and **Command** views.
- Double left click in a **Command** view to bring up a linked **Phase** view.
- Double left click in a **Phase** view to open up a linked **Timing** view.